



Sonification - Sound of Science VU, WS 2013

Lecture 4 - Audification

Visda Goudarzi goudarzi@jem.at





Definition of Audification

The direct playback of data samples. [Krammer, 1992]

Audification is a technique of making sense of data by interpreting any kind of [a] signal as amplitude over time and playing it back on a loudspeaker for the purpose of listening. [Dombois, Eckel, 2011]





Data for Audification

- Sound recorded data (amplified, time stretched or compressed,...)
 e.g ultrasonic bat calls inaudible -> transposed
- Acoustical data (elastomechanics, same physics laws as acoustic waves) e.g. stethoscope, seismographs with acceleration factors of 2,000 and more.
- Physical data (difference velocities compared to acousticly familiar ones) e.g. EEG
- Abstract data e.g. fax machine, stock data





Example

• dark side of the cell (clear pitched sounds from observing the motion of unpertubed Saccharomyces cerevisiae (baker's yeast).)

http://darksideofcell.info/composition.html





Historical Overview (1800 - 1950)

- 1819 Stethoskop (laënnec)
- 1876 Telephone (Bell)
- 1877 Phonograph (Edison)
- 1895 Radiotelegraphy (Marconi)
- 1908 Geiger counter
- 1924 first Audification of bat calls
- WWI-SONAR (Sound Navigation and ranging, idea from da Vinci)
- 1942 Vocoder





- Data Aquisition (sensor data, noise and distortion in data, quantization of sample values -> adds quantization noise to signal -> SNR (signal-to-noise ration), aliasing and clipping, ...)
- 2. Signal Conditioning (e.g. time axis manipulation depending on what the user is looking for e.g. temporal segmentation, coping with artifacts e.g. keeping or removing noisy data before analysis)
- 3. Sound Projection (e.g. multichannel)

The Overall Audification Design depends on:

- The characteristics of the auditory system
- The characteristics of the data set
- The questions that drive the analysis





Characteristics of Human Auditory System

- Frequency Range: 20 Hz 20k Hz (practical only 40 Hz 10 kHz)
- Frequency Resolution: 4Hz in the middle range (1-2 IHz)
- Temporal Resolution: 20 50 ms
- Dynamics Range: I 20 dB at middle frequency (~I kHz)
- Masking Effects: simultaneous masking, temporal masking (e.g. time axis manipulation to avoid it)





The Signal Conditioning Stage

- The best conditioning is no conditioning
- Re-sampling : Nyquist Shannon sampling Theorem: $f_{sampling} > 2 f_{max}$
- Filtering is mostly harmless
- Compress only if there's no other way
- Special tools for special cases:
 - times reverse
 - noise reduction
 - frequency shifter
 - reverb
 - phase vocoder

Sonification - Sound of Science VU, WS 2013





Audification

- Play back at a standard audio sampling rate: 44100 Hz
- When there are fewer values to play per second -> loop or interpolate



Sonification - Sound of Science VU, WS 2013





Example: EEG

- Sampling rate: 44100 Hz
- Data points : d = 250
- Length of Audification: t = 250/44100 = 5.7 [ms] -> 24h data in less than 10 mins
- Compression factor: c = 44100/d = 176.4
- Good for quality control, looking for events
- Transposition = $\log_2(c) = 7.5$ [octaves]
- Alpha waves as an interesting phenomenon :

8 - 13 Hz -> 1411 -2293 Hz (good hearable)







http://www.wegenernet.org



Sonification - Sound of Science VU, WS 2013







Feldbach (Reference Station 77)

Air Temperature and Surface Temperature *hourly* each time for a whole year:

Nov. 2007 - Oct. 2008:

Feldbach_11_2007-11_2008.txt

Nov. 2011 - Oct. 2012:

Feldbach_11_2011-11_2012.txt





Visualization





Intro to SuperCollider



- Boot the Server
- Initialize a Dictionary (e.g. ''q'') for global variables
- Reading DATA
- Define path
- test: File.exists (path)?
- Use a FileReader
- Read the more interesting columns using collect
- Plot Data



Assignment II: Audification due Monday 28.10.13, 11:59:59 pm.



- Load the Data in multiple buffers using buffer.loadCollection
- Load a SynthDef to audify the data
- Play each synth and compare what you hear
- How long does it take to play the whole file?
- Which phenomenon can you hear and how can you adjust the sampling rate to hear it more?
- Compare Air Temperature and Surface Temperature with your audification.
- Compare the two different year of data with your audification and analyze your results.





- Thomas Gorbach lecture on Acousmatics : 8.11.2013 11.00AM
- Open CUBE : Installation of Sonification final projects: March 18th.
- Open CUBE concert KULORK: May 20th.